



# Operation Manual

## eyc-tech FDM06-P

Average Flow Thermal Mass Transmitter



eyc-tech FDM06-P



## Contents

I.	Security considerations.....	2
II.	Operation Form.....	3
III.	Connection Diagram.....	5
IV.	Installation.....	6
V.	RS-485 and Modbus .....	10
VI.	Autozero .....	10
VII.	Software and configuration step.....	11
VIII.	Inspection and maintenance .....	23

## I. Security considerations

Please read this Specification carefully, prior to use of this, and keep the manual properly, for timely reference.

Solemn Statement :

This product can not be used for any explosion-proof area.


Do not use this product in a situation where human life may be affected.

eyc-tech will not bear any responsibility for the results produced by the operators !


### Warning!

- Installation and wiring must be performed by qualified personnel in accordance with all applicable safety standards.
- This product must be operated under the operating conditions specified in manual to prevent equipment damages.
- Please using the product under the ordinary pressure, or it will influence safe problem.
- This product must be operated under the operating condition specified in this manual to prevent equipment damages.
- This product must be operated under the normally atmospheric condition to prevent equipment damages.
- To prevent products damage, always disconnect the power supply from the product before performing any wiring and installation.
- All wiring must comply with local codes of indoor wiring and electrical installation rules.
- Please use crimp type terminal.
- To prevent personal injury, do not touch the moving part of product in operation.
- It may cause high humidity atmosphere during the product was breakdown. Please take safety strategy.

## II. Operation Form



FDM06-P Pitot Tube Thermal Mass Flowmeter A3



The available unit varies depending on the model type.  
Volumetric decimal up to 2 digits, otherwise 3 digits max.


FDM06-P Pitot Tube Thermal Mass Flowmeter A3

### ※Key Pad Operation Mode

Button Instruction	Operation Mode	
	Normal Mode	Menu Mode
Press UP once	Reserved	increase number or option once
Press OK once	Go Menu Mode	Submit the selection, go on next menu or complete the setting and then return to the normal mode
Press DOWN once	Reserved	decrease number or option once, shift cursot if numerical menu
Hold UP	Reserved	increase number or option faster
Hold OK 5 seconds	Reset Totalizer	Return to previous menu, or leave menu mode
Hold DOWN	Reserved	decrease number or option faster
Press UP and DOWN simultaneously	Set Flow Zero	Not Available



## III. Connection Diagram








\*Please make sure the product and the device which connect with RS-485 are on common ground, avoid damaged product.

## IV. Installation

The installation method and conditions of the wind speed sensor will directly affect its measurement accuracy and stability. To ensure optimal performance, be sure to follow these recommendations:

### 1. Installation location and flow conditions

The measuring probe should be installed in the laminar flow state of the flow field, avoiding the turbulent section. It is recommended to keep a long enough straight pipe section before and after the sensor to ensure the flow field conditions. Because elbows, valves, reducers, filters, etc. can cause airflow turbulence and affect measurement accuracy, please refer to the table below to calculate the recommended straight pipe length based on different pipe diameter styles.


Type	Drawing	Upstream straight pipe	Downstream straight pipe
Light bend ( $< 90^\circ$ )		10 x D	10 x D
T-junction		15 x D	10 x D
Two $90^\circ$ bends in one plane		20 x D	5 x D
Two $90^\circ$ bends with 3-dimensional Change in direction		35 x D	10 x D
Shut-off valve		45 x D	10 x D

## 2. Keep away from heat or cold sources

Because thermal mass wind speed sensors are extremely sensitive to temperature, they should be installed away from equipment that produces significant thermal effects (such as electric heaters, air conditioning vents, etc.). This especially refers to temperature changes caused by cold and heat sources. Drastic changes in gas temperature will affect measurement stability and may even result in measurement values that exceed accuracy specifications.

## 3. Probe insertion depth and angle requirements

The probe must be fully inserted into the pipe and the measuring holes must be evenly distributed in the pipe. When installing the thermal mass sensor, the actual airflow should flow in the direction indicated by the airflow direction symbol marked on the sensor. At the same time, in order to achieve accuracy specifications, the angular deviation between the gas flow direction and the installed indicator symbol should be maintained within  $< \pm 3^\circ$ .



Insertion angle deviation or incorrect airflow direction affects measurement accuracy




#### 4. Gas Condition Effects and Scaler Factor

Thermal mass sensors calculate flow rate based on the thermal conductivity and specific heat capacity of the gas. Therefore, when the measured gas is different from the calibration conditions, the thermal mass sensor will calculate a different flow rate. The measuring range of this product is defined under standard conditions of 1013 mbar and 20 °C. The fluid medium is air and it is suitable for measuring applications such as compressed air. When measuring a gas different from the calibration standard, the following table gives correction suggestions based on the thermal properties of the gas such as thermal conductivity, specific heat, density, etc., reflecting the difference in heat transfer caused by the thermal mass sensor. It should be noted that the actual value will also be affected by the gas composition and concentration.

gas	Scaler Factor (Approx.)	Remark
Nitrogen (N <sub>2</sub> )	~ 1.00	Very similar to the properties of air (about 78% of air is N <sub>2</sub> )
Oxygen (O <sub>2</sub> )	~ 1.03	Slightly higher thermal conductivity, but also slightly higher density
Carbon dioxide (CO <sub>2</sub> )	~ 1.33	High density, low thermal conductivity, poor heat transfer, low readings
Argon (Ar)	~ 1.18	Inert gas, high density, low thermal conductivity

### 5. Flow volumetric rate calculation and profile factor

When the gas passes through the duct, the viscosity between the gas and the duct wall causes the wind speed near the wall to be zero (No-slip condition). As the distance from the duct wall increases, the wind speed gradually increases and reaches the maximum value at the center of the cross section. Therefore, the wind speed is non-uniformly distributed in the cross section of the pipe and the distribution of wind speed varies with the size of the pipe and the wind speed. When the wind speed measured by the wind speed measuring tube cannot effectively maintain the average wind speed, if it is directly used as the basis for estimating the air volume, it will lead to deviations in the total air volume estimation. At this time, the volumetric rate calculation can be adjusted using the profile factor.



Typical gas velocity distribution in a pipeline. The average Pitot tube can obtain the average air velocity measurement value.

### 6. Other considerations

During installation, strong vibration or pipe bending and deformation should be avoided, which may affect the stability of the sensor or damage the probe, and avoid vibration and mechanical stress. A location that is easily accessible should be chosen to facilitate subsequent inspection, correction or cleaning. If the installation environment is humid or the gas contains a lot of dust, it is recommended to use a filter or clean it regularly. Because the probe of the thermal mass sensor is particularly sensitive to dust and dirt, the readings will be affected over the long term.

## V. RS-485 and Modbus

FDM06-P integrates a RS-485 interface for digital communication as an option feature. Based on Modbus protocol makes the general convenience on PLC, HMI and PC connection. For Modbus protocol information please download the file from website. Besides the PLC, HMI application, the user software provide the device setting and data logging function, it also can free download from website.

Technical Data :

- (1) Max. network size : 32 transmitters
- (2) Communication : with COM-Port (serial interface) of PC
- (3) Max. network expansion : 1200m (3937ft) total length at 9600 baud
- (4) Transmission rate : 9600, 19200, 38400, 57600, 115200 Baud
- (5) Parity : None, Even, Odd
- (6) Data length : 8 bit
- (7) Stop bit : 1 or 2 bit
- (8) Factory default Station address = 1, Data format= 9600, N81

## VI. Autozero


The middle button allows user to set the current flow rate to zero point. It is required to press the button about 5 seconds, and user can see Auto Zero will be display. Then user can release this button and will see the prompt Auto Zero Done, and the new zero point has been set. Please make sure that the gas is completely still prior to execute this function.

This button also allows user to restore factory default setting. It is required to press the button about 10 seconds, user will first see Reset Zero will be display. Then user can release this button and will see the prompt Reset Zero Done, and the new zero point has been set.


## VII. Software and configuration step

User may download the configuration software on eyc-tech web site. Please decompress the application prior to execute it. Operating System requirements : above Windows 10.

1. Hardware connection : Connect the FDM06-P to PC through USB to RS-485 or RS-232 to RS-485 converter
2. Check the COM port number from Device Manager in Computer Management. e.g. COM1 in illustration




3. Open the FDM06-PC UI, go to function " Interface " , click item " Config " and then setting COM port, BAUD rate, data format and Station ID, pressed " Apply " for connection



#### 4. Scan RS-485 connection

Open the FDM06-P UI, go to function "Interface", click item "Config" and then setting COM port, pressed "Scan" bottom for scan devices and pressed "Close and Export" when the interested devices found.



Pick up the device that you want to connect to and then press "Apply" to go.

## 5. Setting on Analog Output

In the group of Analog, Output tab. The output1 related setting could be found.

Quantity : Flow Velocity in unit of m/s, Flow Velocity in unit of ft/s, Flow Rate in unit of L/min, Flow Rate in unit of m/h, Flow Rate in unit of m/min

(1) Response rate : 1<sup>st</sup> order low pass filter inside, set 100 if filter disable and set 0 if the maximum response time. 100~0 possible. Lower value if lower fluctuation but longer response time, higher value if allow higher fluctuation but shorter response time.

(2) Analog Type : Voltage or Current

(3) Analog Range : 0 ... 20 mA / 4 ... 20 mA (if output current) / 0 ... 10 V (if output voltage)

(4) Decimal Places : Up to 4 decimal places. Please note that the number of displayed digits is a fixed maximum of 5 digits, and the decimal digits need to occupy integer digits.


(5) Range for Display Upper and Lower

(6) Alarm Mode: Check the box if analog output pretends an alarm switch output

(7) Alarm Trigger Point: Upper and Lower

(8) Alarm Output Level: Upper and Lower

(9) Apply: Write the setting value to the device. If this button is not clicked, the changes will be discarded.



File Interface About

Display **Output** Setting Interpolation Information

**Analog**

(1) Quantity **m/s**

(2) Response Rate **98**

(3) ☐ Voltage ☒ Current

(4) Analog Range **4-20mA**

(5) Decimal Places **1111.1**

(6) Upper Range **60.0**

Lower Range **0.0**

(7) ☐ Alarm Mode

Upper Point **48.0**

(8) Lower Point **42.0**

Upper Level **20.0**

(9) Lower level **4.0**

**Relay**

Alarm Level **Low**

Error Reaction **None**

Set Point **0.1**

Hysteresis **0.0**

Delay On **0**

Delay Off **0**


**Apply(10)**

Open Port, Read successful

## 6. Setting on Relay Output

In the group of Relay, Output tab. The relay related setting could be found.

- (1) Alarm Level : Relay activate mode, activate at increasing signal (High) or activate at decreasing signal (Low)
- (2) Error Reaction Mode : None if disable, Hold if memory and hold the first alarm until reboot, Action if active when alarm assert, Deaction if inactive when alarm assert
- (3) Set Point : Activation Set Point
- (4) Hysteresis : Activation Hysteresis Gap
- (5) Delay On : Relay Activate Delay Time in second
- (6) Delay Off : Relay Deactivate Delay Time in second
- (7) Apply: Write the setting value to the device. If this button is not clicked, the changes will be discarded.



eyc-tech UI\_FDM06-P\_V1.0.1-20250418 Station 1\*

File Interface About

Display Output Setting Interpolation Information

**Analog**

Quantity m/s

Response Rate 98

☐ Voltage ☒ Current

Analog Range 4-20mA

Decimal Places 1111.1

Upper Range 60.0

Lower Range 0.0

☐ Alarm Mode

Upper Point 48.0

Lower Point 42.0

Upper Level 20.0

Lower level 4.0

**Relay**

(1) Alarm Level Low

(2) Error Reaction None

(3) Set Point 0.1

(4) Hysteresis 0.0

(5) Delay On 0

(6) Delay Off 0

(7) Apply

Open Port, Read successful

## 7. Offset adjustment and RS-485 Setup

There are 3 groups in setting tab. The description of each item as below.

※ Offset adjustment :

- (1) Flow Velocity/Rate Offset
- (2) Flow Velocity/Rate Low Cut Off Level
- (3) Flow Velocity/Rate scaler factor

※ Process Parameter

- (4) Pipe Type
- (5) Pipe Dimension, specify diameter or width and height
- (6) Flow profile factor

※ Display :


(7) LCD display of measurement: Two programmable on-site display columns are provided, namely the first and second lines of the display. The possible measurement including flow velocity unit in m/s, ft/s and flow rate unit in L/m, m<sup>3</sup>/h and m<sup>3</sup>/m. The position of decimal places can be specified individually.

- (8) Device menu access password
- (9) LCD brightness

※ Modbus Protocol :

- (10) Station ID
- (11) Baud Rate
- (12) Data Frame, the combination of parity check and stop bit





eyc-tech UI\_FDM06-P\_V1.0.1-20250418 Station 1\*

File Interface About

Display Output **Setting** Interpolation Information

**Offset**

(1) Flow Offset (m/s) 0

(2) Low Cut Off (m/s) 0

(3) Scalar Factor 1

Apply Read

**Process**

(4) Pipe Type Round

(5) Inner Diameter (DN) 25

(6) Profile Factor 1

Apply Read

**Display**

(7) Line 1 m/s 1111.1

Line 2 L/m 1111.1

(8) Password 0

(9) Brightness 10

Apply Read

**Modbus Protocol**

(10) Station ID 1

(11) Baud Rate 9600

(12) Data Frame None-8Bit-1Stop


Apply Read

Read Setting, Read successful

## 8. Linear Interpolation

Click the Interpolation tab to specify linear interpolation points.
















- (1) interpolation table
- (2) interpolation curve
- (3) interpolation input column, device measures value (raw value)
- (4) interpolation output column, device output value (standard value or correction value)
- (5) read the interpolation table of connected device
- (6) Clear the interpolation table on configuration software. Note: this action will not modify the interpolation table of the device
- (7) apply, the interpolation would be written in device
- (8) enable, activate the interpolation calculation. When a green rectangle as shown below is displayed under the button, it means that interpolation is enabled, otherwise the interpolation function is turned off



## 9. Data display and logging


On the Display tab, display the measurement data and log the data. The settings are as follows.

※button function description

	clear chart
	change chart drawing line style
	select the activate channel to be set color
	set the activate channel line color
	capture drawing chart screen
	export measurement data since the last "clear chart" or ui start up
	Y-axis label On/Off
	X-axis label On/Off
	secondary Y-axis On/Off
	chart legend On/Off
	data log function On/Off
	
1 Minute	The X-axis scale adjustment
	
Auto Scale	The Y-axis scale mode
	

※Set recording time interval


- File > Log Interval
- Select recording interval




※Export/recording measurement

1. export measurement data since ui start up or the last "clear chart"

1-1. click Display > Export




1-2. Specify the file path and file name > Save




Note: If the specified file already exists, the data will be overwritten.

2. Record measurement data: record data since the Log function is turn on

2-1. Clock Display > Log(OFF)




2-2. Specify the file path and file name > Save > Log(ON)




Note: If the specified file already exists, the data will be overwritten.

2-3. Finish recording measurement data: Click Log(ON) again. At this time, the button returns to displaying Log(OFF), and the recorded data file is stored in the specified file.



10. Device Information
  - (1) Serial Number of Device
  - (2) Model Name of Device
  - (3) Firmware Version of Device
  - (4) Factory Mode Status, default Disable
  - (5) Firmware Checksum
  - (6) Output equipment, supports analog output and relay functions
  - (7) Supported Unit Conversion
  - (8) Totalizer function, default enable
  - (9) Temperature Calibration Points
  - (10) Analog Output Calibration points
  - (11) Calibration Date



The screenshot shows a software window titled "eyc-tech\_UI\_FDM06-P\_V1.0.1-20250418 Station 1\*". The window has a menu bar with "File", "Interface", and "About". Below the menu bar is a tabbed interface with tabs for "Display", "Output", "Setting", "Interpolation", and "Information". The "Information" tab is selected, showing a list of device parameters and their values.

(1) Serial Number	EYC000000001	(4) Factory (MNF) Mode	Enable
(2) Model Name	FDM06-P	(5) Firmware Checksum	1A6C
(3) Firmware Version	1.0.1	(6) Output	Analog, Relay
(7) Unit Conversion	m/s, ft/s, L/min, m³/hour, m³/min		
(8) Totalizer	Disable		
TS1 (°C)	0.00, 100.00		
(9) TS2 (°C)	0.00, 100.00		
(10) DAC Calibration Points			
Voltage (V)	0.350, 1.500, 4.000, 6.000, 10.000		
Current (mA)	4.000, 8.000, 12.000, 16.000, 20.000		
(11) Calibration Date	2025-4-21		

Read FCM01 Information, Read successful

## VIII. Inspection and maintenance

### 1. Maintenance

Since this product is inspected and calibrated for high accuracy at the factory before shipment, no calibration on the installation site is necessary when this product is installed

For inspection and maintenance follow the instructions below :

#### (a) Periodic inspection

Periodically inspect this product for its sensing accuracy, and clean the pitot tube channel. Set the period between inspections based on atmospheric dust and other contaminants in the installation environment

#### (b) Sensor maintenance

Do not damage sensor surface during maintenance process

#### (c) Troubleshooting

If any problem occurs during operation, refer to the table below for appropriate solutions

### 2. Troubleshooting :

Problem	Cleck items	Soluations
<ul style="list-style-type: none"> <li>●No output</li> <li>●Unstable output</li> </ul>	<ul style="list-style-type: none"> <li>●Disconnected wiring</li> <li>●Loose wiring</li> <li>●Power supply voltage</li> <li>●Sensor damages</li> </ul>	<ul style="list-style-type: none"> <li>●Re-perform wiring</li> <li>●Crew on terminal tightly or replace wires</li> <li>●Clean up the pitot tube channel</li> <li>●Replace the sensor</li> </ul>
<ul style="list-style-type: none"> <li>●Slow response to output</li> <li>●Error in output</li> </ul>	<ul style="list-style-type: none"> <li>●Moisture / Condensation on the product</li> <li>●Execute Autozero before measures</li> <li>●Check installed location</li> <li>●Check pitot tube channel</li> <li>●Check dust and contamination on the sensor</li> </ul>	<ul style="list-style-type: none"> <li>●Remove the sensor cover and filter. Let the sensor unit dry naturally in a clean air environment</li> <li>●Refer to the section 6. Autozero</li> <li>●The straight length of pipe did not satisfy design specifications. Refer to the section 4. Installation</li> <li>●Cleanup the pitot tube channel</li> <li>●Calibrate</li> <li>●Replace the sensor</li> </ul>



# eyc-tech Measuring Specialist

enhance your capability with **sensor** technology

Air flow | Humidity | Dew point | Differential pressure | Liquid flow

Temp. | Pressure | Level | Air quality | Signal meter